


RRI-BI120T CORDLESS SHUT OFF IMPACT WRENCH

Edition B



Index No.	Part No.	Description	Q'ty
1	32001-IWCP-01	Upper Housing Assembly	1
2	32002-IWCP-01	Lower Housing Assembly	1
3	0-152001	Screw (Ø3 × 14L)	13
4	0-194014	Spring Washer	2
5	33110-IWCP-01	Cover	1
6	33109-IWCP-03	Button	1
7	32076-IWCP-02	LED Indicator Board	1
8	32086-IWCP-01	Connector Wire	1
9	32083-IWCP-02	Brushless Motor ;w/driver	1
	32106-B180E-01	(1) Connector	1
10	33139-PWAP-01C	Ring	1
	32050-IWCP-01	Gear Box Assembly	1
11	33250-IWCP-01	(1) Gear Box	1
	0-201027	(2) Ball Bearing	1
12	0-121005	Screw (M4 × 10L)	2
13	33249-IWCP-03	Gear Ring	1
14	33239-IWAP-01	Washer	1
15	0-511050	Pin	3
16	0-211003	Needle Bearing	3
17	33249-IWCP-02	Planet Gear	3
18	33243-IWCP-06	Shaft	1
19	33239-IWBP-02	Washer	1
20	33239-IWCP-01	Washer	1

Index No.	Part No.	Description	Q'ty
21	33239-IWCP-01	Washer	1
22	33248-IWBP-01	Spring	1
23	33239-IWAP-02	Washer	3
24	0-521006	Steel Ball (Ø3)	28
25	33245-IWCP-01	Driving Hammer	1
26	0-521024	Steel Ball (Ø7/32")	2
27	33243-IWCP-04	Anvil	1
28	0-411018	O-Ring	1
29	33239-IWCP-04	Washer	1
	32041-IWCP-01	Front Cover Assembly	1
30B	32042-IWBP-01	(1) Bushing Assembly	1
	0-451031	(2) O-Ring	1
	33241-IWCP-01	(2) Front Cover	1
31	0-194001	Spring Washer	4
32	0-151010	Screw (Ø4 × 25L)	4
33	32009-IWCP-01	F/R Valve (1set x 2pcs)	1
34	33248-IWCP-01	Spring	1
35	32076-IWCP-01	PC Board	1
36	32186-IWCP-01	Connector Wire	1
37	32009-PWAP-03	Trigger Assembly	1
38	33248-PWAP-01	Spring	1
39	33139-PWAP-02	Washer	1